




APPLICATION INSTRUCTIONS

①




Thoroughly clean the lcd before applying screen protector, minust of dust will result in bubble.(best way to check is to look at reflections at the grazing angle as shown in the figure)

②



Peel approx. one third length of screen protector using the corner as shown above

③



Fold the release paper of the exposed area underneath as shown in the figure

④



Hold the protector as shown and align the top edge of the protector with the top edge of the screen, as indicated (keep approx 0.5 mm gap if possible)

⑤



Once satisfied with alignment, carefully run the finger as shown so that part of the exposed protector adheres to the screen and take the release paper off

⑥



Once the screen protector rests on the screen, use your finger (or credit card) to press in only one direction (from already attached end) to squeeze out all the major (more then approx 3 mm dia) bubbles.

⑦



Do not try to reposition or repeal the protector for next 12-24 hours and all the minor bubbles will disappear (you can continue using your device normally)

NOTE

Screen protectors are slightly smaller then the screen to take care of any misalignment during the application process.

If the screen protector contains holes or cuts start application by aligning the edge nearest to cut.